





CLEANING MATRIX


		DRY METHODS			WET METHODS (tiles must be cleaned using dry methods before wet cleaning)								
		A1: Soft brush A2: Clean, dry, soft white cloth A3: Vacuum system (with brush)	A4: Focus compressed air	H: Pencil erasers to remove fingerprints or pencil marks	B1: Moist cloth with no detergent C1: A moist cloth with mild detergent diluted in warm water	B2: Damp sponge with no detergent C2: Damp sponge with mild detergent diluted in warm water	D: Damp rough texture sponge (using medium pressure)	F: High pressure water cleaning	G: Resistant to popular disinfectants (due to large number of types of disinfectants, always test a small area first)				
MINERAL SOLUTIONS	ULTIMA+, ULTIMA+ dB, ULTIMA+ OP	✓	Daily	✓	✓	Weekly	✓	Weekly					
	OPTIMA	A1 & A3 Only	Daily	✓			B2 Only	Weekly					
	PERLA, PERLA dB PERLA OP 0.95, PERLA OP 1.00	✓	Daily		✓	Monthly	✓	Weekly					
	NEEVA COLORTONE NEEVA	✓	Daily	✓									
	SIERRA / SIERRA OP	✓	Daily	✓	✓	Monthly	✓	Weekly					
	SAHARA, SAHARA dB, SAHARA MAX COLORTONE Dune eVo	✓	Daily				✓	Weekly					
	PLAIN, GRAPHIS	✓	Daily	✓									
	FINE FISSURED	✓	Daily	✓									
SPECIFIC SOLUTIONS	BIOGUARD ACOUSTIC OP BIOGUARD ACOUSTIC	✓	Daily	✓	✓	Daily	✓	Daily	✓	Weekly		✓	Daily
	BIOGUARD PLAIN	✓	Daily	✓	✓	Monthly	✓	Weekly				✓	Weekly
	SANIGUARD	✓	Daily		✓	Monthly	✓	Weekly					
	CLEANROOM FL	✓	Daily	✓	✓	Weekly	✓	Weekly				✓	Weekly
	PARAFON HYGIEN	✓	Daily	✓	✓	Weekly	✓	Weekly		✓ ⁽¹⁾	Twice Yearly		
	HYDROBOARD	✓	Daily	✓									
	CERAMAGUARD	✓	Daily	✓	✓	Weekly	✓	Daily					
	NEWTONE	✓	Daily	✓			✓	Weekly					
WOOD SOLUTIONS	Plain surface for all veneers	✓	Daily		B1 Only	Weekly							
	Perforated surfaces for all veneers	✓	Daily		B1 Only	Weekly							
METAL SOLUTIONS	Plain surface for all edge details	✓	Daily	✓	✓	Daily	✓	Daily		✓ ⁽²⁾	Twice Yearly	✓	Daily
	 Plain surface with TrioGuard™ coating for all edge details	✓	Daily	✓									
	Perforated surfaces Rg 0501, Rg 0701 for all edge details	✓	Daily	✓	✓	Daily	✓	Daily				✓	Daily
	Perforated surfaces Rg 2516, Rd 1522 for all edge details	✓	Daily	✓	✓	Weekly	✓	Weekly				✓	Weekly


 Wipeable with a dry cloth / soft brush. (A1 - A2 - A3)


 Can be cleaned using focus compressed air. (A4)

 Wipeable with a moist cloth. (B1 - C1)

 Washable with a sponge dampened in water containing mild soap or diluted detergent. (B2 - C2)

 Scrubbable with water containing mild soap or diluted detergent. (D)

 Can be cleaned using a high pressure water spray. (F)

 Can be cleaned with disinfectants commonly used in healthcare premises. (G)

⁽¹⁾ Special instructions are available. Please consult us.
⁽²⁾ Only Q-Clip and R-Clip when sealed with silicone mastic. Special instructions are available. Please consult us.